


Elvox 8875 (Electronic Call)



Terminals

- B
- 1 Speech In (Speaker)
 - 2 Speech Out (Mic)
 - 3 Common ([link to 4/5](#))
 - 6 Call
 - 7 Lock



IMPORTANT NOTE :


1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).

2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).



WIRING DIAGRAM

1 Way Audio With 931 Power Supply





1 Way Audio With 936 Power Supply



INTERPHONE
type 8875
type 8872



INTERPHONE
type 6200




CH 3 2 1 S




- A- Entrance panel series GALILEO, GALILEO SECURITY or PATAVIUM
- B- Additional push-button for lock
- C- Electric lock 12V~
- D- Speech unit type 930/836 - 930F
- L1- Panel bulb
(3x24V 3W max.)
10x24V 3W with type M832
16x24V 3W with type 832/030

2 Entrance System With 931 Power Supply



- A- Entrance panel series GALILEO SECURITY, GALILEO or PATAVIUM
- B- Additional push-button for lock
- C- Electric lock 12V~
- D- Speech unit type 930 or 930A
- L1- Panel bulb
(3x24V 3W max.)
10x24V 3W with type M832
16x24V 3W with type 832/030

2 Entrance System With 936 Power Supply



- A- Entrance panel
series GALILEO SECURITY
GALILEO or PATAVIUM
- B- Additional push-button for lock
- C- Electric lock 12V~
- D- Speech unit type Type 930/836, 930F
- L1- Panel bulb
(3x24V 3W max.)
10x24V 3W with type M832
16x24V 3W with type 832/030